

SOUTH PRODUCTION NOTES

May 29, 2014
Afternoon Shift

BASF EMPLOYEES
84 Last Recordable
334 Last Lost Time

F1 is on manual

#1 MED / ICL-8:

Continue to make batches after the solution pump is fixed, but do not get more than 3 bags ahead of the calciner. Continue to keep a close eye on diameters. Anything from .129" to .133" is ok but anything higher than .133" will prompt a die change on the extruder. Check the oil in reservoir.

Midnight shift:

Day shift: Solution pump has been repaired. Re-started the extruder.

Afternoon shift:

#1 RC / ICL-8:

Calciner is ready but the feed was shut off for repairs to vertical dust collector. Watch each drum for discoloration (tan) and isolate any of these drums for refeeding. If drum material looks all white, apply label and close. If material is tan, place label on top of drum for refeeding (tape it so it does not get lost).

Feed rate 400-425. We will feed the refeed drums at a reduced temp (drop to 760 degrees) if needed.

Midnight shift:

Day shift: Stopped feed while repairs were made to vertical dust collector. We have re-started the feed.

Afternoon Shift:

Exhaust to Trimer for ICL-8 (F1 pump failed)

#2 MED line/ Cu-0860 is Next:

Continue running and sampling per the MOD. Use the wet mix cart for cleaning out the barrel and add it back into the mixer. Do not create wet mix drums unless we know we have a bad batch of material that needs to be drummed off.

Midnight shift:

Day Shift: Continue running. Make sure we ice out the barrel.

Afternoon Shift:

#2 RC/ Cu-0860:

Continue per the MOD.

Midnight Shift:

Day shift: Continue.

Afternoon shift:

Exhaust to F1

#3 MED line / D-0768:

We are only using Phibrotech copper carb. **WRITE BATCH NUMBERS ON YOUR BAGS COMING OFF THE DRYER. Change inserts every 4-5 batches.**

Midnight Shift: Finished last wet mix batch.

Day shift: Line is done we can start clean up. Clean out sheet available.

Afternoon Shift:

#3 RC / D-0768:

Down until temperature controller is fixed. We are feeding regular phibrotech material.

Midnight shift: Down. Unable to control temperatures once again.

Day shift: After a second round of troubleshooting, the calciner feed has been re-started.

Afternoon Shift:

Exhaust to Trimer (out of HEPA filters for CTO)

#4 RC / Cu 0360:

Feed will start into size 113 bags for first 6000 lbs (material will be repacked later), then follow MOD for drumming instructions.

Midnight Shift: Shut down due to possible contamination issues. Notify N. Trent in the morning to look at material. It looks as though there is 5206 as well as some broken pills.

Day shift: Discharge chute and slide gate taken apart and cleaned. Feed re-started. Currently feeding the three contaminated drums through spiral elevator. 5206 material will screen out. We will feed the bags (1-3) at end of run at lower or no temperatures.

Afternoon Shift:

Exhaust to 4A DC

#5 RC / Cu-3818:

HOLD UNTIL THURSDAY MORNING INSPECTION. We will only use Phibrotech copper and the material will be discharged onto a 120 bag. Feed rate is at 14.0 hz.

Midnight shift:

Day shift: Determination has been made to strengthen the I-beam that holds the hoist over the feed hopper. This work is being performed today. After work has been completed verify that we can re-start the feed.

Afternoon shift:

Exhaust to 5A DC

PK Blender / Na Selexorb Intermediate next:

Waiting for instructions. Building, day tank and PK have been rinsed.

Midnight Shift: No change.

Day shift: No activity.

Afternoon shift: No activity

Old Pfaudler – D-0754:

In addition to the drainage sample we were collecting we must also collect a sample of each batch (8 oz baggy) and a sample of the solution tank. Make sure that all samples are properly labeled. Send to the lab for evaluation – this is a customer request let's make it happen with EVERY batch we make. Make sure that we add on the batch sheet any drainage collected and add to the label of the sample the batch number.

Midnight Shift:

Day Shift: No activity –

Afternoon Shift: Holding until dryer repairs completed

#6 RC / D-0754:

Remember that we are to take a single large sample (not two, just one) per MOD and we need to collect a chemi sample that will be collected only during midnight shift. When running, be sure to:

(1) Get pallet and empty bag weight, write with marker on side of pallet and on check-weigh sheet. On pallet mark it "Tare * lbs; (2) Fill bag, record net weight on sheet and add to tare weight; (3) Take full bag and pallet to check scale and re-weigh. Record check-weight on sheet and record difference on sheet.**

Midnight shift:

Day Shift: Sly scrubber has been repaired. The #6 dryer is being worked on by maintenance currently (Otero).

Afternoon shift:

**Exhaust to Sly Scrubber
HC-11 Tanks Cu-5020 :**

Finished/Tanks need cleaned.

Midnight shift: Tank 107 currently draining to wastewater. Tank 6 is clean.

Tank 4 has acid water in it that will need to be pumped to 107 and drained.

Day shift: Cleaning #4 Tank and T-107. Discovered that T-5's pump is plugged again.

Afternoon Shift:

New Pfaudler / Cu 0226-start on Next Tuesday :

Need cleaning instructions

Midnight shift: No activity

Day shift: No activity

Afternoon Shift:

Abbe Blender – D-5206:

We can run on the weekend and off shifts. Make sure to read Grodecki's instructions at the end of the shift notes regarding how to match up lots of 5202.

Midnight shift:

Day shift: No activity.

Afternoon shift:

National Dryer / D-5206:

Feed as material becomes available.

Midnight Shift: feeding as material is available.

Day shift: Feeding as material is available.

Afternoon Shift: Feed as material available

Tower 3 / Cu-1155:

Loaded. Started running.

Midnight Shift: Loaded and running. May unload late on 2nd shift or into 3rd shift.

Day shift:

Afternoon shift: Continue

Tower 6 / 930 VAM:

Loaded and running. Each tower load will take 5 super sacks filled with 8 drums.

Midnight Shift: Maybe ready to unload late on day shift.

Day shift: Not unloaded yet. Will be unloaded on second shift.

Afternoon shift:

North Screener / Switch to DPT-101:

We need to double band all of the socks to the bins BEFORE OPENING ANY BINS – use the newly acquired adjustable quick disconnect hose clamps. Make sure that we hit the MOD rate.

Midnight shift:

Day shift: No activity.

Afternoon Shift:

South Screener / Cu-1155:

We need to double band all of the socks to the bins BEFORE OPENING ANY BINS – we have now in place the newly acquired adjustable quick disconnect hose clamps. Make sure that we hit the rate required.

Midnight shift:

Day shift: Continue

Afternoon Shift:

#2662 (east) Pill Machine / Zr-0403 1/8: Hold

Started to clean up and take apart machines in preparation for Zr material. We will use only one dust collector.

Midnight shift: No change

Day Shift: No change

Afternoon shift: No change

#2664 (west) Pill Machine / Zr-0403 1/8: Hold

Started to clean up and take apart machines in preparation for Zr material. We will use only one dust collector.

Midnight shift: No change

Day Shift: No change

Afternoon shift: No change

TK #2 V 2046:

All saggars have been changed over to V 2046. The kiln has been lit and is currently up to temperature. We have material to feed so we can start the process. The Dust collector was repaired by maintenance.

Midnight shift:

Day Shift: Kiln is up to temp. We can start loading on second shift.

Afternoon shift:

At screeners: all totes need to have two bands fastened to sock before opening a new tote.

Work notification to place duct work hangers on the second floor (bldg. 31) – 934147915.

Work notification written to cap / remove ductwork around #3 mixer – 934147916.

1. Fines need to be recorded daily on the green sheet.

Priorities for the week

- 1. Our Safety**
- 2. EH&S equipment**
- 3. Reduction Towers**
- 4. #3 MED / #3 RC – D-0768**
- 5. #5 RC – Cu-3818**
- 6. #1 RC – Al-3992 re-fires**
- 7. Old Pfaudler / #6 Dryer, RC – D-0754**
- 8. Abbe / National Dryer / #4 RC – 5206**
- 9. Strikes – Cu 5020**